

# Florida Impact Door Systems, Inc.

3850 West Industrial Way  
West Palm Beach, FL 33404

(561) 841-8590

Fax (561) 841-9440



## INSTALLATION INSTRUCTIONS

- 1) Clean hands before handling
- 2) Store all doors laid flat
- 3) Do not trim door edges
- 4) Install long screws #12 x 2-1/2" (furnished) 2 per hinge through jambs into buck
- 5) Install long screws #10 x 2-1/2 through stop at hinge location to level jamb
- 6) Use surface mounted closers only

*Complete drawings and details of our  
Miami Dade NOA's are available on line at*

[www.floridaimpactdoors.com](http://www.floridaimpactdoors.com)